/ Setup guide Regular Speaker System



1



Plug the True1 Power Plug into the power input of the speaker. Turn the plug to the right until it says 'click'.

Plug the XLR signal male plug of the combination cable into the speaker input connection.



2

3



Plug the XLR signal female plug into your audio mixer or DJ mixer.

Plug in the Schuko Power Plug into a power supply near the mixer. You can use the 4-way multi-socket for cable length and split.



4



You can now switch on all equipment and adjust to the desired volume. You are all set now to use the equipment.

To dismantle this audio set, please run the above-mentioned instructions in reverse (step 5 to 1)