

Setup guide Regular Speaker System



1



Tilt the subwoofer 90 degrees and unlatch the wheel dolly.

Run the multicable with the red strap to the subwoofer.
Plug the True1 Power Plug into the power input of the subwoofer.



2

3



Plug the XLR signal male plug of the multicable into the speaker input connection of the subwoofer.

Plug the XLR signal female plugs of the multicable into your audio mixer or DJ mixer.



4

5



Plug in the Schuko Power Plug of the multicable into a power supply near the mixer. You can use the 4-way multi-socket for cable length. and split.

Connect the True1 Powerplug of the multicable with the yellow strap to the power output of the subwoofer.



6

7



Plug the XLR signal female plug of the multicable with the yellow strap in the Thru output of the subwoofer.

Connect the True1 Powerplug of the multicable with the yellow strap to the power input of the speaker.



8

9



Plug the XLR signal male plug of the multicable with the yellow strap into the speaker input.

You can now switch on all equipment and adjust to the desired volume. You are all set now to use the equipment.



10

To dismantle this audio set, please run the above-mentioned instructions in reverse (step 10 to 1)